

## 80 Meter Skip Distance Chart



80 Meter Skip Distance Chart





- Select the F2 layer ionosphere height  $h_mF2$  from the appropriate Ionosonde Site by clicking on Ionogram under the Current Conditions tab of the web site www.skywave-radio.org (for example Port Arguello, CA hmF2 = 250 km)
- Then select the current critical frequency Fc by clicking on Ionogram Port Arguello foF2 under the Current Conditions tab (for example foF2 = 3 MHz)
- From intersection of height (hmF2 = 250 km) and Fc (Fc = 3 MHz) traces read down to the Distance axis
- This is the approximate skip distance for the current conditions (300 miles in this example)